




## ASSEMBLY INSTRUCTIONS

### READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS TABLE SHOULD TAKE APPROXIMATELY 5 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

### UNPACK THE LAMP

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: METAL COVER, GLASS PANEL, POLE ASSEMBLY, BASE AND TRANSFORMER. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

### ASSEMBLE THE LAMP

1. CAREFULLY ORGANIZE AND PLACE ALL PARTS ON A SMOOTH, FLAT SURFACE. LINE UP ALL OF THE PARTS ACCORDING TO THE ASSEMBLY DIAGRAM.
2. SCREW POLE ASSEMBLY TO TOP OF BASE.
3. PLACE GLASS PANEL ON TOP OF DISTRIBUTOR. (NOTE: MAKE SURE THE BEVELED SIDE IS FACING DOWNWARDS.)
4. SCREW METAL COVER TO DISTRIBUTOR TO SECURE THE GLASS PANEL.
5. INSERT CONNECTOR INTO INPUT JACK IN POLE AS SHOWN.
6. PLUG TRANSFORMER INTO AN OUTLET AND TURN ON AT PIN SWITCH.
7. PRESS RED PUSH SWITCH TO CHANGE THE LED LIGHTS COLORS CONTINUOUSLY, PRESS THE RED PUSH SWITCH AGAIN, THE LED LIGHTS WILL NO LONGER CONTINUOUSLY CHANGE COLORS.

### TROUBLE SHOOTING

1. IF YOUR LED TABLE DOES NOT LIGHT, CHECK PLUG AT THE OUTLET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE POWER OUTLET.
2. IF THE LED TABLE STILL DOES NOT LIGHT, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.